

Усилитель серии У000 (артикул У003)



***DETONATOR***

Ламповый гитарный усилитель



Руководство  
по эксплуатации

**YERASOV®**

# YERASOV®

---

1.	.....	1
2.	.....	2
3.	.....	2
	CLEAN CHANNEL .....	3
	BRIGHT    CLEAN GAIN .....	4
	LEAD CHANNEL .....	5
	BRIGHT    LEAD GAIN .....	5
	DAMPING .....	6
	PRESENCE    MASTER .....	6
4.	.....	7
	EFFECT LOOP .....	7
	.....	8
	FOOTSWITCH .....	8
	SPEAKERS .....	9
	PENTOD –TRIODE .....	10
	FUSE .....	10
5.	.....	10
	TUBE SELECT .....	10
6.	.....	11
7.	.....	12
8.	.....	12
9.	.....	13

1.

## *DETONATOR*

:

10

:

:

## 2.

1. Footswitch

FS-33

2.

**Bull 412**

8

3.

4.

30

POWER

ON ( )

“STANDBY”

5.

STANDBY  
MASTER

ON ( ),

6.

STANDBY

ON ( ).

!

STANDBY

5-10

POWER

1.

(FS).

CLEAN

2.

SEND LEVEL

3. EFFECT LOOP

:


SERIAL- PARALLEL. EFFECT LOOP  
 SERIAL,  
 FOOTSWITCH.  
 SEND LEVEL RETURN LEVEL  
 RETURN LEVEL  
 MASTER.

4.

SEND LEVEL

RETURN LEVEL  
 SEND LEVEL.

3.



POWER. INPUT

GAIN –

**DETONATOR,**  
 GAIN

VOLUME –

TREBLE –

GAIN.

( MIDDLE BASS),

MIDDLE –


MIDDLE

BASS –

TREBLE  
BASS MID

TREBLE

## CLEAN CHANNEL



## DETONATOR

BRIGHT CLEAN GAIN

BRIGHT –

1  
OFF.

2



GAIN.  
GAIN,  
BRIGHT.  
GAIN BRIGHT

CLEAN GAIN –  
SINGLE HUMB

– HUMB

« » « »  
« »


HUMB  
SINGLE  
HI CLEAN

## DETONATOR

CLEAN CHANNEL

GAIN MIDDLE

## LEAD CHANNEL



LEAD CHANNEL –



CLEAN(FS)

LEAD CHANNEL

LO LEAD HI LEAD,

LEAD

LO  
HI LEAD –

**BRIGHT LEAD GAIN**

BRIGHT –



1. BRIGHT OFF  
2. BRIGHT CLEAN CHANNEL.  
: OFF, 1 2.  
BRIGHT LEAD CHANNEL  
BRIGHT ( OFF)

LEAD GAIN –

: VINTAGE, BOOST VINTAGE MODERN.


VINTAGE LO LEAD

« »-

BOOST VINTAGE –

MODERN

## DETONATOR



## DAMPING

OFF DAMPING

DETONATOR ON

PRESENCE MASTER

PRESENCE

PRESENCE

PRESENCE


MASTER

POWER

STANDBY.




4.



## EFFECT LOOP

EFFECT LOOP.



1.  
**DETONATOR**

(SERIAL)  
(PARALLEL)

SERIAL/PARALLEL.


2. SEND LEVEL  
**DETONATOR**
3. SEND
4. RETURN
5. RETURN LEVEL SERIAL

SEND RETURN. EFFECT LOOP


( RETURN LEVEL),  
5 dB,  
4 dB.

1. SEND.
2. RETURN.
3. SEND LEVEL
4. RETURN LEVEL.
5. SERIAL-PARALLEL.  
 SEND LEVEL RETURN LEVEL  
 RETURN LEVEL  
 MASTER. (SERIAL)  
 RETURN LEVEL  
 (PARALLEL)  
 RETURN LEVEL

## FOOTSWITCH




FS-33. CHANNEL  
 CLEAN CHANNEL  
 LEAD CHANNEL  
 LEAD  
 HIGH LOW.  
 LEAD CHANNEL  
 HIGH LEAD  
 LOOP.  
 FS-33,  
 CLEAN (FS).



## SPEAKERS

### DETONATOR

4 , 8 16 .



SPEAKERS

(4 TUBES)

(2 TUBES)

! 4TUBES/2TUBES

( . ).

4 TUBES

4 (

8 (

8 ),

16 )

16 .

2 TUBES

8 (


16 )

16 .

BULL 412

8 .

## PENTODE – TRIODE



PENTODE  
 TRIODE – , « ».

### DETONATOR

1. 100W – 4 TUBES PENTODE;
2. 50W – 4 TUBES TRIODE;
3. 50W – 2 TUBES PENTODE;
4. 25W – 2 TUBES TRIODE.

!  
 ( )

STANDBY.

## FUSE



( . . 2 – 4).

5.

## TUBE SELECT

TUBE SELECT,



(6L6 EL34).  
 6L6

EL34 ( ),

distortion

TUBE SELECT

6.

ECC83

ECC83

EL34 (6L6)

c

## 7.

		.....	1
		4TUBES:	
TRIODE, ,		.....	50
PENTODE, ,		.....	100
		2TUBES:	
TRIODE, ,		.....	25
PENTODE, ,		.....	50
	50 ,	.....	220±22
		.....	300
		.....	650 225 250
( , ) ,		.....	18
		.....	5xECC83, 1x12AX7WA, 4xEL34(6L6)

## 8.

	<b>DETONATOR,</b>	.....	1
	FS-33,	.....	1
	T 3,15 A,	.....	1
		.....	1
	1 ,	.....	1
		.....	1
		.....	1

9.

12

\*

!

-

:

-

-

-

\*

1

**DETONATOR**

**DETONATOR**

60065, 22505,  
51515, 51317.3.2-2006  
( . . 6,7), 51317.3.3,  
RU. 02. 05122

YERASOV MUSIC CORPORATION  
440003, / . (8412) 93-03-56, 93-03-60. 20.  
**WWW.YERASOV.RU**

YERASOV MUSIC CORPORATION  
440003,  
/ . (8412) 93-03-56, 93-03-60.  
E-mail: sale@yerasov.ru

20.

**YERASOV MUSIC CORPORATION**  
**[www.yerasov.ru](http://www.yerasov.ru) e-mail: [sale@yerasov.ru](mailto:sale@yerasov.ru)**